
Central Patching Location

- 1. DCS 10U 11 Slot Director Patch Panel Enclosure
- 2. DCS 48 Channel Adapter Panel
- 3. 48 Channel-96 Fiber Trunk LC-LC
- 4. Director 48 Port Blade
- 5. Cisco 9513 Director Switch
- 6. LC-LC Patch Cable
- 7. DCS 6U 24 Channel LC Adapter Panel
- 8. DCS 6U 8 Slot Modular Patch Panel Enclosure



Fiber Trunk out to Equipment Distribution Area Zone Patching Location